

GRAYDON MONITORING CENTRE




Protecting People and Property Since
1973

Procedures for Testing Your Alarm System

All Alarm Systems should be periodically tested to ensure devices are functioning and that alarm conditions can be transmitted to the central station. Only regular testing can ensure your system is fully functioning.

We can provide full testing of your alarm system with a service call, but you can also self test your system by following these basic instructions.

- 1) Call Graydon Monitoring Centre (GMC) to tell them you are going to test your alarm system. 1-866-206-4466
- 2) Give them your CSID # (this is also your Acct# on your invoice) and your password.
- 3) Arm your system with your PIN as you do when you leave, open and close your entry/exit door.
- 4) When the arming delay has counted down move in front of a motion detector to initiate alarm condition. You may now test as many devices as you wish by opening protected doors or windows or passing in front of motion detectors. Lastly open your entry exit door.
- 5) Certain devices such as glass break detectors, smoke detectors, heat detectors, carbon monoxide detectors, and water detection devices should be tested by a qualified technician.
- 5) The siren must sound for at least one minute to ensure the signal is transmitted to GMC.
- 6) Enter your PIN to disarm your system as normal. You may re-arm the system and then immediately disarm the system to clear the memory lamp.
- 7) Call Graydon Monitoring Centre and let them know you are finished testing and verify that signals have been received. They will then return your alarm account status to fully active.



If you have any questions, are having any troubles, or just want more information, please contact your local service office. Telephone numbers and locations can be found on our website below.



www.graydongroup.ca

email: accountchanges@graydongroup.ca